

Inter-Locking Flashing System

TRI-BUILT® Millennium Lockin' Pocket® Parents Pending



1. Place TRI-BUILT® Millennium Lockin' Pocket® with at least 1" clearance from inside of Pocket and penetration.



2. Mark outside edge for reference.



3. Seal base of penetration with TRI-BUILT® Millennium Locken' Pocket® Sealant.



4. Apply a liberal bead of TRI-BUILT® Millennium Locken' Pocket® Sealant to the substrate.



5. Apply a liberal bead of TRI-BUILT® Millennium Locken' Pocket® Sealant to the locking joint of Pocket.



6. Set TRI-BUILT® Millennium Lockin' Pocket® in place.



7. Apply equal pressure to assure positive contact with roof surface.



8. Strike away excess sealant.



9. Dispense and discard an initial amount of TRI-BUILT® Millennium Hurricane Force® Universal Sealer* to ensure a proper mix.



10. Fill assembled Pocket with TRI-BUILT® Millennium Universal Sealer* until full.

NOTE:

- Substrate to receive Lockin' Pocket® must be clean and free of loose gravel, dirt, granules, or any other foreign substance that could affect adhesion.
- When installed on a single ply membrane the surface of the membrane must be prepared according to the single ply manufacturer's recommendations.
- EPDM: Clean with splice wash or surface cleaner and prime. TPO: Clean with surface cleaner and prime. Gravel BURs: Remove gravel surfacing down to plies.
- Do not dispense initial amount of TRI-BUILT® Millennium Hurricane Force® Universal Sealer into pocket.

*TRI-BUILT® Millennium Hurricane Force® Universal Sealer sold separately