



NOTE:
 TRI-BUILT ROOF X TENDER EX 915 FLUID FLASH SHOULD BE APPLIED UNDER AND ABOVE SOLARMOUNT/SUNFRAME.
 *FOR OPTIONAL ADDITIONAL SECUREMENT, TRI-BUILT POLYESTER CAN BE IMBEDDED. SEE IMAGE.

TRI-BUILT ROOF X TENDER RX 915 FLUID FLASH
 SOLARMOUNT/SUNFRAME L-FOOT INSTALLATION

