



TRI-BUILT® MATERIALS GROUP, LLC

SYNTHETIC 10

SYNTHETIC ROOF DECK PROTECTION

TRI-BUILT® SYNTHETIC 10 Installation Instructions:

TRI-BUILT® SYNTHETIC 10 is synthetic roof-deck protection designed and manufactured to replace asphalt saturated #15 felt in sloped roof system construction.


- TRI-BUILT® SYNTHETIC 10 is considered an air, vapor and water barrier and therefore must be installed above properly ventilated attic space(s).
- All applicable building codes in your geographic area and specific to the building structure type must be followed as the product is considered a vapor barrier.
- The roof deck must be clean of debris, solid, properly fastened and free of voids and/or damage.
- TRI-BUILT® SYNTHETIC 10 must be installed printed side up and unrolled parallel to the roof eave.
- The use of straight edge cutting knives is recommended.
- Plastic cap nails must be used when being exposed longer than 1 day and up to 30 days to secure TRI-BUILT® SYNTHETIC 10 properly. The plastic cap fasteners should be a minimum of 1" in length and have caps a minimum of 1" in diameter.
- Roofing nails are acceptable when installing TRI-BUILT® SYNTHETIC 10 under a sloped standing-seam metal roof installation and should be driven flush to the surface without cutting into the sheet.
- The plastic cap fastener spacing should be a minimum of 6" o.c. horizontally along the indicated fastener placement areas at the top and the bottom of the sheet, and at 12" o.c. in the center fastener placement locations on the sheet. If installation of the prepared roofing cover in the same day, use of every other anchoring location printed in the field of the underlayment is acceptable.
- If product is to be covered with asphalt shingles, stone coated metal roofing or sloped installation of standing seam metal panels within 1 day TRI-BUILT® SYNTHETIC 10 can be installed with corrosive resistant 3/8" head by 1" minimum length roofing nails (ring shank recommended).
- Top and bottom overlaps should be 4" minimum as indicated by the lay-up fastener lines printed on the sheet.
- End overlaps should be a minimum of 6" and fastened at 12 o.c., vertically along the overlaps at 2" in from the end of the top layer. For extended exposure periods, over 10 days, a minimum of 12" end overlap is required.
- The plastic cap nails should be driven flush to the surface of the TRI-BUILT® SYNTHETIC 10 without cutting into the sheet.
- Repair all damage to the TRI-BUILT® SYNTHETIC 10 before proceeding. For seams, joints or tears, repairs may be made using self-stick flashing tape or the equivalent. Asphalt adhesives may also be used to seal joints, flashings and laps.
- TRI-BUILT® SYNTHETIC 10 should be extended at least 12" past all hips and valleys.
- TRI-BUILT® SYNTHETIC 10 installed on less than 4:12 slopes should be applied in a double coverage method, (overlapping by the normal 4" application is acceptable). Fastening can be through both layers on less than 4:12 slopes.
- For extended exposure, or where driving rains and/or strong winds, double the lap widths as a minimum precaution. Alternatively, fold the overlay laps to form a "j - channel" configuration before nailing; using a compatible sealant between the laps, or using a peel and stick tape is highly recommended. For batten secured installations, do not install battens directly over any cap nails. If this occurs, remove cap nail, patch the hole, then install the cap nail outside the batten field and continue.
- Where seams and joints require a sealant or adhesive, use a high quality, low solvent, asbestos free, plastic roofing cement that meets ASTM D-4586 Type1 (Asbestos Free), Federal Spec SS-153 Type 1 (Asbestos Free). Acceptable alternatives are butyl rubber, urethane, and EPDM based caulk or tape sealants.
- Follow the ARMA (Asphalt Roofing Manufacturers Association) recommendations for installing shingle underlayments and flashings for best roofing practices.
- Depending on roof pitch and surface condition, blocking may be required to support materials on the roof.
- TRI-BUILT® SYNTHETIC 10 is not designed for indefinite outdoor exposure. Finished roofing should be installed within 30 days.

CAUTIONS: SAFETY FIRST

As with any roofing product, always learn and follow safe roofing practices according to OSHA and local building code requirements and use and wear proper fall protection devices when working on roofs. Always use caution when walking on sloped roof decks and TRI-BUILT® SYNTHETIC 10 underlayment as slip resistance may vary with surface conditions, weather, footwear and roof pitch. Do not walk on unsecured TRI-BUILT® SYNTHETIC 10 or any other loose roofing material lying on sloped roof decks. Dust, dew, water or debris creates unsafe conditions on the roof. The presence of any foreign material may drastically change the coefficient of friction (traction) on TRI-BUILT® SYNTHETIC 10 or any other material on a sloped roof deck. Failure to always use proper safety equipment and footwear can result in serious injury or even death.

COMPLIANCE: CODES

- Performance characteristics meet or exceed ASTM D4869 – Type I, II, III and IV
- Performance characteristics meet or exceed ASTM D226 – Type I, II
- Tested in accordance with ICC-AC-207 – Ultraviolet Exposure – 180 days
- ASTM E108 – Class A Fire – Passed
- ASTM D6757 – Inorganic Shingle Underlayment Standard
- UL Classified as a Prepared Roofing Accessory
- Meets requirements of ICC-AC-188
- Limited Warranty – 15 years



PHYSICAL DATA		
Roll Size	48" X 250'	48" X 100'
Material Per Roll	1,000 sq. ft.	400 sq. ft.
Squares Per Roll	10 squares	4 squares
Weight Per Roll	21 lbs	10 lbs
Roll Type	STANDARD <input type="checkbox"/>	SAMPLE <input type="checkbox"/>

Made in India

TRI-BUILT® Materials Group, LLC • PO Box 70 • Rutherford, NJ 07070 • 800-516-1485
visit us at www.tribuiltmaterialsgroup.com